

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

NEON SENSOR COMMAND, CONTROL, AND CONFIGURATION: LEVEL TROLL 500

| PREPARED BY | ORGANIZATION | DATE |
|----------------|--------------|------------|
| Charles Bohall | AQU | 08/28/2013 |

| APPROVALS | ORGANIZATION | APPROVAL DATE |
|------------|--------------|---------------|
| Dave Tazik | CCB PROJ SCI | 01/13/2014 |
| Hanne Buur | CCB DIR SE | 01/17/2014 |
| | | |
| | | |

| RELEASED BY | ORGANIZATION | RELEASE DATE |
|---------------|--------------|--------------|
| Stephen Craft | SE | 02/19/2014 |

See configuration management system for approval history.

© 2014 NEON Inc. All rights reserved.

The National Ecological Observatory Network is a project solely funded by the National Science Foundation and managed under cooperative agreement by NEON, Inc. Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the National Science Foundation.

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

Change Record

| REVISION | DATE | ECO # | DESCRIPTION OF CHANGE |
|----------|------------|-----------|-----------------------|
| A | 02/19/2014 | ECO-01541 | Initial release |
| | | | |
| | | | |

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

TABLE OF CONTENTS

| | | |
|----------|---|----------|
| 1 | DESCRIPTION..... | 1 |
| 1.1 | Purpose | 1 |
| 1.2 | Scope..... | 1 |
| 2 | RELATED DOCUMENTS AND ACRONYMS | 1 |
| 2.1 | Applicable Documents | 1 |
| 2.2 | Reference Documents..... | 2 |
| 2.3 | External References | 2 |
| 2.4 | Acronyms | 2 |
| 3 | INTRODUCTION | 2 |
| 4 | OVERVIEW OF SENSOR CONFIGURATION | 3 |
| 5 | COMMAND AND CONTROL | 3 |
| 5.1 | Error handling | 3 |
| 5.2 | Sensor controls specification | 4 |
| 6 | ASSEMBLY INTEGRATION | 4 |
| 7 | APPENDIX & BIBLIOGRAPHY | 4 |

LIST OF TABLES

| | | |
|-----------------|---|---|
| Table 1. | L0 data products acquired from In-Situ Inc. Level TROLL | 2 |
| Table 2. | Sensor configuration settings | 3 |
| Table 3. | Data quality codes..... | 3 |

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

1 DESCRIPTION

1.1 Purpose

This document specifies the command, control, and configuration details for operating a NEON sensor used for instrumental observations. It includes a detailed discussion of all necessary requirements for operational control parameters, conditions/constraints, set points, and any necessary error handling. All Level 0 Data Products generated by the sensor should be identified.

1.2 Scope

This document specifies the command, control, and configuration that is needed for operating the In-Situ Inc. Level TROLL 500; used to make measurements of surface water level in lakes and streams. The Level TROLL measures the surface water pressure of surface water bodies where sensors are deployed. The Level TROLL holds its calibration constraints within internal memory and performs the analog to digital data conversion internally before any data output occurs.

| LEVELTROLL 500 NEON P/N 0317680000 | FIRMWARE VERSION |
|------------------------------------|------------------|
| Surface Water Pressure | 2.07 |
| Surface Water Temperature | 2.07 |

This document specifies the command, control, and configuration that is needed for operating this sensor. It does not provide implementation details, except for cases where these stem directly from the sensor conditions as described here. No command and control is required at the time of deployment. Only sensor configuration is required at the time of deployment.

2 RELATED DOCUMENTS AND ACRONYMS

2.1 Applicable Documents

Applicable documents contain information that shall be applied in the current document. Examples are higher level requirements documents, standards, rules and regulations.

| | | |
|---------|------------------|---------------------------------------|
| AD [01] | NEON.DOC.000001 | NEON Observatory Design |
| AD [02] | NEON.DOC.000291 | NEON Configured Sensor List |
| AD [03] | NEON.DOC.005003 | NEON Scientific Data Products Catalog |
| AD [04] | NEON.DOC.005005 | NEON Level 0 Data Products Catalog |
| AD [05] | NEON.DOC. 001198 | ATBD for LevelTROLL 500 (TBW) |

2.2 Reference Documents

Reference documents contain information complementing, explaining, detailing, or otherwise supporting the information included in the current document.

| | | |
|---------|-----------------|------------------------|
| RD [01] | NEON.DOC.000008 | NEON Acronym List |
| RD [02] | NEON.DOC.000243 | NEON Glossary of Terms |

2.3 External References

External references contain information pertinent to this document, but are not NEON configuration-controlled. Examples include manuals, brochures, technical notes, and external websites.

| | |
|---------|---|
| ER [01] | In-Situ Inc. Level TROLL Manual Revision 007 May 2012 |
|---------|---|

2.4 Acronyms

| Acronym | Explanation |
|----------------|--|
| ATBD | Algorithm Theoretical Basis Document |
| C ³ | Command, Control, and Configuration Document |
| SOP | Standard Operating Procedures |
| QA/QC | Quality Assurance/Quality Control |
| AIS | Aquatic Instrumentation System |
| L0 | Level 0 |
| L1 | Level 1 |
| ENG | NEON Engineering group |
| CI | NEON Cyberinfrastructure group |
| DPS | NEON Data Products group |
| CVAL | NEON Calibration, Validation, and Audit Laboratory |

3 INTRODUCTION

The sensor configuration and sensor command and control described here are related to the surface water pressure. The parameters will be measured by the Level TROLL at each sensor set location at NEON aquatic sites. The sensor is assumed to communicate through an RS-422 connection. As mentioned above the analog to digital conversion, as well as the conversion to calibrated units is performed within the Level TROLL prior to output of the data for ingestion by the data acquisition system. Table 1 below details the data measurement streams and associated L0 data product ID's.

Table 1. L0 data products acquired from In-Situ Inc. Level TROLL

| Parameters | L0 data products |
|--------------------------|---|
| Pressure | NEON.DXX.XXX.DP0.XXXXXX.XXX.XXX.XXX.XXX |
| Pressure Data Quality ID | NEON.DXX.XXX.DP0.XXXXXX.XXX.XXX.XXX.XXX |

* As of Rev A of this document, the AQU data products catalog is TBW. This table will be updated when that catalog becomes available.

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

4 OVERVIEW OF SENSOR CONFIGURATION

Data coming from the sensors is defined in Table 1, above. Table 2 below details the Data Streams coming from the sensors, the required data collection frequency, the units coming directly from the sensor, and base units.

Table 2. Sensor configuration settings

| DATA STREAMS | DATA COLLECTION FREQUENCY | DATA STREAM UNITS |
|---------------------------|---------------------------|-------------------|
| Surface Water Pressure | 1/60 Hz | kPa |
| Surface Water Temperature | 1/60 Hz | deg. C |
| Battery Voltage | 1/60 Hz | V |
| Data Quality ID | 1/60 Hz | Whole Number |

5 COMMAND AND CONTROL

The Level TROLL does not include equipment that requires remote command and control through the location controller; however initial set-up of the sensor will select, as a built-in option, to collect the data as a linear average of 3 measurements collected in a burst collection and averaged to a single point measurement.

5.1 Error handling

The Level TROLL does not report errors that need to be addressed, but does include quality codes for the collected data which will be output as a data stream. The following codes apply to all Data Quality ID data streams.

Table 3. Data quality codes

| Id | Name | Description |
|----|---------------|--|
| 0 | Normal | Parameter measured without errors using a current calibration. |
| 1 | User Uncal | Parameter measured without errors using an expired user calibration. |
| 2 | Factory Uncal | Parameter measured without errors using and expired factory calibration. |
| 3 | Error | Parameter measured with error, sentinel value supplied. |
| 4 | Warm-up | Sensor is warming up, sentinel value supplied. |
| 5 | Disabled | Sensor is disabled, sentinel value supplied. |
| 6 | Calibrating | Sensor is calibrating, calibration value supplied. |
| 7 | Off Line | Device is off line, sentinel value supplied. |
| 8 | Warning | Parameter measured without errors but does not meet normal quality criteria. |

| | | |
|--|-------------------|------------------|
| Title: NEON Command, Control, and Configuration: Level Troll 500 | | Date: 02/19/2014 |
| NEON Doc. #: NEON.DOC.001175 | Author: C. Bohall | Revision: A |

5.2 Sensor controls specification

The Level TROLL will be configured in the RS-422 menu to the above settings. The Level TROLL will receive a query by the location controller. The Level TROLL will respond with the preconfigured data stream.

6 ASSEMBLY INTEGRATION

All assembly integration is handled by the sensor internally in the Level TROLL. The data output from the Level TROLL has already been converted from analog to digital signal with calibration constraints applied.

7 APPENDIX & BIBLIOGRAPHY

In-Situ Inc. LevelTROLL Manual Revision 007 May 2012

<http://www.in-situ.com/products/water-level/level-troll-family/level-troll-500-instrument>