

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

NEON SENSOR COMMAND, CONTROL, AND CONFIGURATION (C3) DOCUMENT: WET DEPOSITION

| PREPARED BY: | ORGANIZATION: | DATE: |
|--------------|---------------|------------|
| Hongyan Luo | FIU | 12/17/2015 |

| APPROVALS (Name): | ORGANIZATION: | APPROVAL DATE: |
|-------------------|---------------|----------------|
| Andrea Thorpe | PROJ SCI | 1/11/2016 |
| Dave Tazik | SCI | 1/07/2016 |
| Maurizio Miccolis | SI&V | 1/07/2016 |
| | | |

| RELEASED BY (Name): | ORGANIZATION: | RELEASE DATE: |
|---------------------|---------------|---------------|
| Anne Balsley | CM | 1/13/2016 |

See Configuration Management System for Approval History.

© 2016 NEON Inc. All rights reserved.

The National Ecological Observatory Network is a project solely funded by the National Science Foundation and managed under cooperative agreement by NEON, Inc. Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the National Science Foundation.

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

Change Record

| REVISION | DATE | ECO # | DESCRIPTION OF CHANGE |
|----------|-----------|-----------|--|
| A | 9/23/2014 | ECO-01455 | Initial Release |
| B | 1/13/2016 | ECO-03566 | Revise document using the new C3 document template, updated DP numbers to new format |
| | | | |

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

TABLE OF CONTENTS

1 DESCRIPTION.....1

1.1 Purpose 1

1.2 Scope..... 1

2 RELATED DOCUMENTS AND ACRONYMS3

2.1 Applicable Documents 3

2.2 Reference Documents..... 3

2.3 External References 3

2.4 Acronyms 3

3 INTRODUCTION (DGD 0335070000, AB03960000).....4

4 OVERVIEW OF SENSOR CONFIGURATION (DGD 0335070000, AB03960000).....4

5 COMMAND AND CONTROL5

5.1 Error Handling..... 5

5.2 Sensor <device> controls specification..... 5

6 ASSEMBLY INTEGRATION5

7 APPENDIX.....5

7.1 List of Level 0 data product..... 5

7.2 Assembly schematic drawing 7

8 BIBLIOGRAPHY7

LIST OF TABLES

Table 2 Heater and chiller configuration settings..... 4

Table 4 Truth table for power status error handling 5

Table 5. List of Level 0 data product associated with DPName: Wet Deposition..... 6

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

1 DESCRIPTION

1.1 Purpose

This document specifies the command, control, and configuration details for operating the wet deposition collection assembly (e.g., N-CON sampler and associated infrastructures). It includes a detailed discussion of all necessary requirements for operational control parameters, conditions/constraints, set points, and any necessary error handling. All Level 0 Data Products generated by the sensor are identified. Raw data from the sensor are compensated by the DAS, but received at HQ for further processing as a L0 unfiltered and uncorrected data product until its associated algorithms are applied to produce a quality-controlled and -assured L1 data product in standard scientific units.

1.2 Scope

This document specifies the command, control, and configuration that are needed for operating this wet deposition collector. It does not provide implementation details, except for cases where these stem directly from the sensor conditions as described here.

A complete set of the Level 0 data products generated in this document can be found in appendix. The wet deposition assembly will consist of following Data Generating Device (DGD) based on Data Generating Device DGD List and Hierarchies doc (AD [05]):

| DGD Agile PN | DGD Agile Description |
|--------------|--|
| 0335070000 | Sensor, Wet Deposition Sampler, NEON Custom |
| AB03960000 | Assembly, Cable, PRT Submersible, 6 Feet, NADP |

Further detailed sensor info under each DGD is as following:

1. Under 0335070000:

- Sensor, Wet Deposition Sampler, NEON Custom, NEON P/N 0335070000. Manufacture: N-Con Systems Company, Inc. Manufacture model number: NEON 00-127-7. This model has dual funnel and dual bottle design.
- Other accessories:
 - Sensor Acry, Thermoelectric Chiller, NEON Custom, for N-Con Atmospheric Deposition Sampler, NEON P/N 0345760001
 - 2 sets of Glass funnel, Glass anti-evaporation capillary, Glass sample bottle, Capacity: 2 liters, (NEON P/N 0303560003)

2. Under AB03960000:

- Sensor Thermometrics Aquatic RTD Sensor 5.0 inch Probe with No Cable and No Connector, NEON P/N 0317690001

This dual bottle wet deposition collector is relatively new to the market. No official manual is available yet. But its operating principle is identical to the N-CON MDN model sampler (model 00-125-4).

| | | |
|--|-----------------------|------------------------|
| <i>Title:</i> NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | <i>Date:</i> 1/13/2016 |
| <i>NEON Doc. #:</i> NEON.DOC.001421 | <i>Author:</i> H. Luo | <i>Revision:</i> B |

Therefore, we can use N-CON MDN manual as the reference document RD [03], until such time as the TM model manual becomes available.

This C³ document specifies the command, control, and configuration that are needed for operating this sensor and accessories. It does not provide implementation details, except for cases where these stem directly from the sensor conditions as described here.

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

2 RELATED DOCUMENTS AND ACRONYMS

2.1 Applicable Documents

Applicable documents contain information that shall be applied in the current document. Examples are higher level requirements documents, standards, rules and regulations.

| | | |
|---------|-----------------|---|
| AD [01] | NEON.DOC.000001 | NEON Observatory Design Requirements |
| AD [02] | NEON.DOC.000291 | NEON Configured Sensor List |
| AD [03] | NEON.DOC.005003 | NEON Scientific Data Products Catalog |
| AD [04] | NEON.DOC.005005 | NEON Level 0 Data Products Catalog |
| AD [05] | NEON.DOC.003495 | Sensor Maintenance Procedures: Wet Deposition |

2.2 Reference Documents

Reference documents contain information complementing, explaining, detailing, or otherwise supporting the information included in the current document.

| | | |
|---------|-----------------|------------------------|
| RD [01] | NEON.DOC.000008 | NEON Acronym List |
| RD [02] | NEON.DOC.000243 | NEON Glossary of Terms |

2.3 External References

External references contain information pertinent to this document, but are not NEON configuration-controlled. Examples include manuals, brochures, technical notes, and external websites.

| | |
|---------|--|
| ER [01] | N-CON Atmospheric Deposition Sampler Manual Model 00-125-4 |
|---------|--|

2.4 Acronyms

| Acronym | Explanation |
|----------------|--|
| C ³ | Command, Control, and Configuration Document |
| SOP | Standard Operating Procedures |
| QA/QC | Quality Assurance/Quality Control |
| L0 | Level 0 |
| L1 | Level 1 |
| ENG | NEON Engineering group |
| CI | NEON Cyberinfrastructure group |
| PRT | Platinum Resistance Thermometers |
| NADP | North American Deposition Program |
| BASIN | Biogeosphere-Atmosphere Stable Isotope Network |
| GNIP | Global Network of Isotopes in Precipitation |

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

3 INTRODUCTION (DGD 0335070000, AB03960000)

The N-CON Trace Metal (or TM) sampler specifically modified to meet NEON needs is model NEON 00-127-7 (call wet deposition sampler below). It is the sensor that will collect the precipitation samples for the chemistry and water isotopic (¹⁸O and DH) analysis at selected NEON sites. It is equipped with an infrared precipitation sensor that can detect precipitation drops and snowflakes, thus controlling the sampler lid to open and collect the “wet only” deposition samples during the precipitation or snow events, and close the lid thereafter. The dual-funnel/dual-bottle design allows a glass bottle with anti-evaporation capillary to collect samples for water isotopic analysis, and a polyethylene bottle to collect samples for precipitation chemistry analysis. Samples in both glass bottle and polyethylene bottle will be collected manually once every two weeks, indexed/asset tagged and sent to NEON contract labs for analysis following procedures from recognized international organizations (e. g., NADP, BASIN, GNIP, etc.), which will be described in a separate SOP (AD[05]).

This wet deposition sampler is equipped with its own heating and cooling control system, and does not require external commands and controls. A PRT sensor will be used to monitor the chamber temperature.

The data products that are automatically output from this sampler include power status and lid open/close status (see section 4 and Section 7.1 for details). The data products output from the PRT temperature sensor will be temperature in degrees Celsius (see Section 7.1).

4 OVERVIEW OF SENSOR CONFIGURATION (DGD 0335070000, AB03960000)

The PRT sensor here is just used to monitor the temperature inside the sampler chamber and track the function of heater/cooling system. This PRT sensor will stay with assembly until failure. No annual calibration is required. Sensor drift will be monitored by field technicians following the SOPs (AD[05]). The temperature output will be streamed back to CI. Sampling frequency should be 0.1 Hz. See LO DP in Section 7.1.

Digital signals for power status, lid open/close status, and PRT temperature are assumed to be digital and be output through Ethernet.

Manual Sensor Configuration 1: Heater and chiller settings should be pre-configured, and should not be changed during field operations.

For all units NEON will purchase, the heater and chiller are included in the package. Heating system includes an AC heater to control chamber temperature. Chiller is used to control temperature at hot environments. The heater and chiller are controlled by the embedded thermostats inside the chamber, which must be preset at installation and periodically checked during each manual sample collection. Therefore, no external command and control is applied to the operation of the heating and cooling systems. The set-points for the thermostats should be: 3 °C for the heater (i.e., turn on heater when chamber temperature is lower than 3 °C), and 25°C for chiller (i.e., turn on chiller when chamber temperature is above 25 °C). No data outputs from heater and chiller will be streamed back to CI.

Table 2 Heater and chiller configuration settings

| Parameter | Default Setting | Notes |
|-------------------|-----------------|---|
| Heater thermostat | 3°C | turn on heater when temperature is below 3 °C |

| | | |
|--------------------|------|---|
| Chiller thermostat | 25°C | turn on chiller when temperature is above 25 °C |
|--------------------|------|---|

When chamber temperature is out of range (<3°C or >25°C), an out of range flag will be generated at HQ as a L1 DP. Because there is no need of this flag for any command and control function, it is not required to generate it as a L0 DP at site by DAS.

Manual Sensor Configuration 2: settings for infra-red precipitation sensor should be pre-configured and should not be changed during field operations.

The precipitation sensor is an infra-red transmitter and receiver. It is an integral part of the wet deposition sampler that detects precipitation drops or snowflakes, and in turn, controls the sampler lid operation (open lid on 5 drops of onset of precipitation, and close lid at 25 seconds of end of sensed precipitation). During each manual sample collection, quick tests by waving fingers between the precipitation sensor heads should be carried out to ensure the precipitation sensor and lid movements work properly. This procedure will be described in a separate SOP document (AD [05]).

The data streamed to CI include the lid status and the power status. The data will be recorded only when the status changes. See L0 DP list in Section 7.1.

5 COMMAND AND CONTROL

5.1 Error Handling

Table 4 Truth table for power status error handling

| Control parameter(s) | Condition | Data acquisition system action | Output to CI |
|----------------------|---|--------------------------------|--------------|
| Power status | No power to instrument | Send trouble ticket | None |
| chamberTemperature | Running average of 30 min <3°C or >25°C over 2 hours in row | Send trouble ticket | None |

5.2 Sensor <device> controls specification

N/A

6 ASSEMBLY INTEGRATION

N/A

7 APPENDIX

7.1 List of Level 0 data product

| | | |
|---|----------------|-----------------|
| Title: NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | Date: 1/13/2016 |
| NEON Doc. #: NEON.DOC.001421 | Author: H. Luo | Revision: B |

Table 5. List of Level 0 data product associated with DPName: Wet Deposition

| DGD Agile PN | DPNumber | fieldName | description | Acquisition frequency (Hz) | dataType | units |
|--------------|---|--------------------|---|----------------------------|----------|---------|
| 0335070000 | NEON.DOM.SITE.DP0.00013.001.01819.HOR.VER.000 | powerStatus | Power status of the instrument (0=powered; 1=no power) | When status changes | integer | NA |
| | NEON.DOM.SITE.DP0.00013.001.01820.HOR.VER.000 | lidStatusWetDep | Lid status of the wet deposition collector (0=lid closed; 1=lid open) | When status changes | integer | NA |
| AB03960000 | NEON.DOM.SITE.DP0.00013.001.01818.HOR.VER.000 | chamberTemperature | Temperature of the wet deposition chamber | 0.1 | real | celsius |

| | | |
|--|-----------------------|------------------------|
| <i>Title:</i> NEON Sensor Command, Control, and Configuration (C3) Document: Wet Deposition | | <i>Date:</i> 1/13/2016 |
| <i>NEON Doc. #:</i> NEON.DOC.001421 | <i>Author:</i> H. Luo | <i>Revision:</i> B |

7.2 Assembly schematic drawing

N/A.

8 BIBLIOGRAPHY

- N-CON Atmospheric Deposition Sampler Manual Model 00-125-4