



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

NEON SENSOR COMMAND, CONTROL AND CONFIGURATION (C3) DOCUMENT: MULTISONDE, STREAM

PREPARED BY	ORGANIZATION	DATE
Jesse Vance	AQU	01/14/2016
Kaelin M. Cawley	AQU	05/25/2016
Bobby Hensley	AQU	08/15/2019

APPROVALS	ORGANIZATION	APPROVAL DATE
Keli Goodman	AQU	01/17/2020
David Barlow	ENG	01/14/2020

RELEASED BY	ORGANIZATION	RELEASE DATE
Anne Balsley	CM	01/17/2020

See configuration management system for approval history.

The National Ecological Observatory Network is a project solely funded by the National Science Foundation and managed under cooperative agreement by Battelle.
Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of the
National Science Foundation.



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

Change Record

REVISION	DATE	ECO #	DESCRIPTION OF CHANGE
A	02/19/2014	ECO-01541	Initial release
B	05/12/2016	ECO-03752	Expand the number of data streams collected from the Multisonde
C	12/07/2016	ECO-04311	Revision of the tables for the multisonde to link the individual probes to Data Product Numbers
D	06/02/2017	ECO-04760	Revision to include the firmware version and update RAW BGA units to percent.
E	09/03/2019	ECO-06249	Updated firmware versions, inclusion of signal output adapter.
F	01/17/2020	ECO-06351	Added information about Averaging options in the configuration of the body.

Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

TABLE OF CONTENTS

1	DESCRIPTION	1
1.1	Purpose	1
1.2	Scope	1
2	Related documents and acronyms.....	3
2.1	Applicable Documents	3
2.2	Reference Documents.....	3
2.3	Acronyms	3
3	Multisonde, Stream Introduction (HB07530000 (w/FDOM) and HB07530010 (no FDOM))	3
4	Multisonde, Stream Overview of Sensor configuration (HB07530000 (w/FDOM) and HB07530010 (no FDOM)).....	5
4.1	Multisonde, Stream Sensors	5
5	Multisonde, Stream Command and Control (HB07530000 and HB07530010)	6
5.1	Error handling	6
5.2	Sensor controls specification	7
6	Assembly integration	7
7	Appendix.....	8
7.1	List of Level 0 data product.....	8
7.2	Tables for clarification of data stream numbers and calibration status.....	11
7.3	Assembly schematic drawing	16
8	Bibliography	16

LIST OF TABLES

Table 1.	Configuration setting for Multisonde, Stream (HB07530000 and HB07530010)	5
Table 2.	Multisonde wiper configuration, Stream (HB07530000 and HB07530010)	6
Table 3.	Multisonde averaging mode configuration, Stream (HB07530000 and HB07530010)	6
Table 4.	Truth table for sensor error handling.....	6
Table 5.	List of Level 0 data product associated with DPName: Water Quality	8
Table 6.	Data stream numbers and calibration status with FDOM	11
Table 7.	Data stream numbers and calibration status with no FDOM	14

1 DESCRIPTION

1.1 Purpose

This document specifies the command, control, and configuration details for operating a NEON sensor used for instrumental observations. It includes a detailed discussion of all necessary requirements for operational control parameters, conditions/constraints, set points, and any necessary error handling. All Level 0 Data Products generated by the sensor should be identified.

1.2 Scope

This document specifies the command, control, and configuration that are needed for operating this sensor. It does not provide implementation details, except for cases where these stem directly from the sensor conditions as described here.

A complete set of the Level 0 data products generated in this document can be found in appendix.

The multisonde assemblies exist in three instances and will consist of following Data Generating Device (DGD) based on Data Generating Device DGD List and Hierarchies doc (AD [05]):

DGD Agile PN	DGD Agile Description
HB07530000	YSI EXO2 Multisonde with FDOM
HB07530010	YSI EXO2 Multisonde with no FDOM
0320170001	Conductivity/Temperature – YSI EXO sonde
0320170003	Dissolved Oxygen (Optical) – use with YSI EXO sonde
0320170004	Turbidity, use with YSI EXO sonde
0320170005	Total Algae, use with YSI EXO sonde
0320170006	fDOM, use with YSI EXO sonde
0320170015	pH/ORP, unguarded, use with YSI EXO2 sonde

Further detailed sensor info under each DGD is as following:

1. Under DGD HB07530000:
 - a. HB07530000, Sensor, YSI EXO2 Multisonde with FDOM, firmware version 1.0.73
 - b. 0320170001, Conductivity/Temperature – YSI EXO sonde, firmware version 3.0.5
 - c. 0320170003, Dissolved Oxygen (Optical) – YSI EXO sonde, firmware version 3.0.0
 - d. 0320170004, Turbidity, use with YSI EXO sonde, firmware version 3.0.0
 - e. 0320170005, Total Algae, use with YSI EXO sonde, firmware version 3.0.5
 - f. 0320170006, fDOM, use with YSI EXO sonde, firmware version 3.0.0
 - g. 0320170015, pH/ORP, unguarded, use with YSI EXO2 sonde, firmware version 3.0.0



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

2. Under DGD HB07530010:

- a. HB07530010, Sensor, YSI EXO2 Multisonde with no FDOM, firmware version 1.0.73
- b. 0320170001, Conductivity/Temperature – YSI EXO sonde, firmware version 3.0.5
- c. 0320170003, Dissolved Oxygen (Optical) – YSI EXO sonde, firmware version 3.0.0
- d. 0320170004, Turbidity, use with YSI EXO sonde, firmware version 3.0.0
- e. 0320170005, Total Algae, use with YSI EXO sonde, firmware version 3.0.5
- f. 0320170015, pH/ORP, unguarded, use with YSI EXO2 sonde, firmware version 3.0.0

Other important parts that are not a DGD:

3. NEON PN 0320170008, Sensor Accessory – Anti fouling guard for YSI EXO2 sonde.
4. NEON PN 0320170007, Sensor – Central wiper for YSI EXO sonde only
5. NEON PN 0320170017, DCP Signal Output Adapter v1.0 – Connects to YSI field cable and converts signal to RS-232 or SDI-12
6. NEON PN 0320170025, DCP Signal Output Adapter v2.0 – Connects to YSI field cable and converts signal to RS-232 or SDI-12

2 RELATED DOCUMENTS AND ACRONYMS

2.1 Applicable Documents

Applicable documents contain information that shall be applied in the current document. Examples are higher level requirements documents, standards, rules and regulations.

AD [01]	NEON.DOC.000001	NEON Observatory Design (NOD) Requirements
AD [02]	NEON.DOC.000291	NEON Configured Sensor List
AD [03]	NEON.DOC.005003	NEON Scientific Data Products Catalog
AD [04]	NEON.DOC.005005	NEON Level 0 Data Products Catalog
AD [05]	NEON.DOC.001104	Data Generating Device DGD List and Hierarchies
AD [06]	NEON.DOC.00	

2.2 Reference Documents

Reference documents contain information complementing, explaining, detailing, or otherwise supporting the information included in the current document.

RD [01]	NEON.DOC.000008	NEON Acronym List
RD [02]	NEON.DOC.000243	NEON Glossary of Terms

2.3 Acronyms

Acronym	Explanation
ATBD	Algorithm Theoretical Basis Document
AIS	Aquatic Instrument System
C ³	Command, Control, and Configuration Document
SOP	Standard Operating Procedures
QA/QC	Quality Assurance/Quality Control
AIS	Aquatic Instrument System
L0	Level 0
L1	Level 1
ENG	NEON Engineering group
CI	NEON Cyberinfrastructure group
DPS	NEON Data Products group
CVAL	NEON Calibration, Validation, and Audit Laboratory

3 MULTISONDE, STREAM INTRODUCTION (HB07530000 (W/FDOM) AND HB07530010 (NO FDOM))

The sensor configuration and sensor command and control described here are related to the multisonde associated data products. A description of how sensor readings shall be converted to L1 DPs is presented in the associated ATBD (AD[06]). The AIS assembly used to generate these data products consists of multiple components, which vary according to the site type and location within a site. This document describes the assemblies that are deployed at stream sites. At stream sites the components include the

Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

sonde body, pH, DO, turbidity, total algae (chlorophyll a), temperature, conductivity and fDOM sensors, an enclosure and stainless steel infrastructure which allows water to free flow past the sensors which both protecting the multisonde and holding in position. At stream sites there are two measurement locations. The upstream location does not contain the fDOM sensor, while the downstream location does contain the fDOM sensor; otherwise these assemblies are identical.

Configuration settings and the command and control structure are described below in Section 4. The L0 data products resulting from this sensor are listed under Section 7.1 in the appendix.



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

4 MULTISONDE, STREAM OVERVIEW OF SENSOR CONFIGURATION (HB07530000 (W/FDOM) AND HB07530010 (NO FDOM))

4.1 Multisonde, Stream Sensors

The multisonde assemblies shall be configured to output the data streams defined in Table 1, Table 2, and Table 3. The sampling frequency for HB07530000 and HB07530010 is shown in Table 1.

The Multisonde assemblies contain a central wiper that is used to limit the accumulation of biological growth that will impact measurements. The wiper function shall be configured according to Table 2 for the Multisonde assemblies.

The multisonde assemblies should be set to an averaging mode of “accelerated” according to Table 3.

Table 1. Configuration setting for Multisonde, Stream (HB07530000 and HB07530010)

Parameter	Sample Frequency	Units
Actual conductivity	0.0167 Hz	μSiemens/cm
Specific conductivity	0.0167 Hz	μSiemens/cm
Temperature	0.0167 Hz	celsius
Water depth of measurement	0.0167 Hz	Meter
Pressure of surface water	0.0167 Hz	psi
Dissolved oxygen as percent of saturation	0.0167 Hz	%
Dissolved oxygen concentration	0.0167 Hz	mg/L
pH	0.0167 Hz	pH
pH sensor voltage	0.0167 Hz	mV
Raw signal of BGA sensor	0.0167 Hz	%
Blue-green algae (BGA) phycocyanin (PC) concentration	0.0167 Hz	μg/L
Raw signal of chlorophyll sensor	0.0167 Hz	%
Chlorophyll a concentration	0.0167 Hz	μg/L
Raw signal of turbidity sensor	0.0167 Hz	%
Turbidity of water as FNU	0.0167 Hz	FNU
Raw signal of fluorescent dissolved organic matter sensor	0.0167 Hz	%
Fluorescent dissolved organic matter concentration as quinine sulfate equivalents	0.0167 Hz	QSU*
Wiper Position	0.0167 Hz	V
Battery voltage	0.0167 Hz	V
Main voltage	0.0167 Hz	V
Date and Time	0.0167 Hz	Date and Time

* Quinine Sulfate Units



Table 2. Multisonde wiper configuration, Stream (HB07530000 and HB07530010)

Parameter	Setting
Samples per Wipe	5

Table 3. Multisonde averaging mode configuration, Stream (HB07530000 and HB07530010)

Parameter	Setting
Averaging Mode	Accelerated

5 MULTISONDE, STREAM COMMAND AND CONTROL (HB07530000 AND HB07530010)

5.1 Error handling

This is no active or direct error monitoring. However, if the Multisonde output streams exhibit problems the sonde may be queried to determine if there are any internal faults. The sonde reports these internal faults via the SONDE_FULT YSIP command. The fault code be determined by performing the command Get Device Status and looking at bit 4 in the response. Table 4 shows the bit position descriptions.

Table 4. Truth table for sensor error handling.

Device Status Bit Position	Condition	Data acquisition system action	Output to CI
0	Low Battery (<3.6V)	None	None
1	Low External Voltage (<7.5V)	Send trouble ticket	None
2	Low Real Time Clock Battery (<1.8V)	Send trouble ticket	None
3	microSD card Fault	None	None
4	Bluetooth Fault	None	None
5	Sensor Address Fault (address = 0)	Send trouble ticket	None
6	Power/Comms FPGA Fault	Send trouble ticket	None
7	Sensor #1 Over Power (>2000mW)	Send trouble ticket	None
8	Sensor #2 Over Power	Send trouble ticket	None
9	Sensor #3 Over Power	Send trouble ticket	None
10	Sensor #4 Over Power	Send trouble ticket	None
11	Sensor #5 Over Power	Send trouble ticket	None
12	Sensor #6 Over Power	Send trouble ticket	None
13	Sensor #7 Over Power	Send trouble ticket	None
14	Sensor #8 Over Power	Send trouble ticket	None
15	Sensor #9 Over Power	Send trouble ticket	None



16	Sensor #10 Over Power	Send trouble ticket	None
17	Sensor #11 Over Power	Send trouble ticket	None
18	Sensor #12 Over Power	Send trouble ticket	None
19	Sensor #13 Over Power	Send trouble ticket	None
20	Sensor #14 Over Power	Send trouble ticket	None
21	Sensor #15 Over Power	Send trouble ticket	None
22	Sensor #16 Over Power	Send trouble ticket	None
24-31	Reserved	NA	NA

5.2 Sensor controls specification

N/A

6 ASSEMBLY INTEGRATION

N/A



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

7 APPENDIX

7.1 List of Level 0 data product

Table 5. List of Level 0 data product associated with DPName: Water Quality

DGD Agile PN	DPNumber	fieldName	description	Acquisition frequency (Hz)	dataType	units
0320170001	NEON.DOM.SITE.DP0.20005.001.01371.HOR.VER.000	conductance	Conductivity at ambient temperture	0.01667	real	microsiemens PerCentimeter
	NEON.DOM.SITE.DP0.20005.001.01093.HOR.VER.000	specificConduc tance	Conductivity auto-corrected to 25 degrees C	0.01667	real	microsiemens PerCentimeter
	NEON.DOM.SITE.DP0.20005.001.01378.HOR.VER.000	surfaceWaterT emperature	Temperature in surface water	0.01667	real	celsius
HB07530000 or HB07530010	NEON.DOM.SITE.DP0.20005.001.01664.HOR.VER.000	sensorDepth	Water depth of measurement	0.01667	real	meter
	NEON.DOM.SITE.DP0.20005.001.01663.HOR.VER.000	sondeSurface WaterPressure	Pressure of surface water measured by the multisonde in psi	0.01667	real	poundsPerSqu areInch
	NEON.DOM.SITE.DP0.20005.001.01670.HOR.VER.000	wiperPosition	Position of wiper	0.01667	real	volt
	NEON.DOM.SITE.DP0.20005.001.01372.HOR.VER.000	batteryVoltage	Battery voltage	0.01667	real	volt
	NEON.DOM.SITE.DP0.20005.001.01647.HOR.VER.000	sensorVoltage	Main voltage	0.01667	real	volt



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

DGD Agile PN	DPNumber	fieldName	description	Acquisition frequency (Hz)	dataType	units
0320170003	NEON.DOM.SITE.DP0.20005.001.01360.HOR.VER.000	dissolvedOxygen Saturation	Dissolved Oxygen Percent Saturation	0.01667	real	percent
	NEON.DOM.SITE.DP0.20005.001.01151.HOR.VER.000	dissolvedOxygen	Dissolved Oxygen Concentration	0.01667	real	milligramsPerLiter
0320170015	NEON.DOM.SITE.DP0.20005.001.01657.HOR.VER.000	pH	Measurement of pH in water	0.01667	real	pH
	NEON.DOM.SITE.DP0.20005.001.01658.HOR.VER.000	pHvoltage	pH meter voltage	0.01667	real	millivolt
0320170005	NEON.DOM.SITE.DP0.20005.001.01667.HOR.VER.000	blueGreenAlgaeRaw	Raw signal of blue-green algae sensor as a percent of full scale detected in the sample	0.01667	real	percent
	NEON.DOM.SITE.DP0.20005.001.01659.HOR.VER.000	blueGreenAlgaePhycocyanin	Blue-green algae phycocyanin concentration in water	0.01667	real	microgramsPerLiter
	NEON.DOM.SITE.DP0.20005.001.01666.HOR.VER.000	chlorophyllRaw	Raw signal of chlorophyll a sensor as a percent of full scale detected in the sample	0.01667	real	percent
	NEON.DOM.SITE.DP0.20005.001.01660.HOR.VER.000	chlorophyll	Chlorophyll a concentration in water	0.01667	real	microgramsPerLiter
0320170004	NEON.DOM.SITE.DP0.20005.001.01669.HOR.VER.000	turbidityRaw	Raw signal of turbidity sensor as a percent of full scale detected in the sample	0.01667	real	percent
	NEON.DOM.SITE.DP0.20005.001.01662.HOR.VER.000	turbidity	Turbidity of water as FNU	0.01667	real	formazinNephelometricUnit



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

DGD Agile PN	DPNumber	fieldName	description	Acquisition frequency (Hz)	dataType	units
0320170006	NEON.DOM.SITE.DP0.20005.001.01668.HOR.VER.000	fDOMRaw	Raw signal of fluorescent dissolved organic matter sensor as a percent of full scale detected in the sample	0.01667	real	percent
	NEON.DOM.SITE.DP0.20005.001.01661.HOR.VER.000	fDOM	Fluorescent dissolved organic matter concentration as quinine sulfate equivalents	0.01667	real	quinineSulfate Unit



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

7.2 Tables for clarification of data stream numbers and calibration status

Table 6. Data stream numbers and calibration status with FDOM

DGD Agile PN	DPNumber	fieldName	description	Stream Number	Calibration
0320170001	NEON.DOM.SITE.DP0.20005.001.01371.HOR.VER.000	conductance	Conductivity at ambient temperture	0	no
	NEON.DOM.SITE.DP0.20005.001.01093.HOR.VER.000	specificConduc tance	Conductivity auto-corrected to 25 degrees C	1	yes
	NEON.DOM.SITE.DP0.20005.001.01378.HOR.VER.000	surfaceWaterT emperature	Temperature in surface water	2	no
HB07530000	NEON.DOM.SITE.DP0.20005.001.01664.HOR.VER.000	sensorDepth	Water depth of measurement	3	no
	NEON.DOM.SITE.DP0.20005.001.01663.HOR.VER.000	sondeSurface WaterPressure	Pressure of surface water measured by the multisonde in psi	4	no
	NEON.DOM.SITE.DP0.20005.001.01670.HOR.VER.000	wiperPosition	Position of wiper	17	no
	NEON.DOM.SITE.DP0.20005.001.01372.HOR.VER.000	batteryVoltage	Battery voltage	18	no
	NEON.DOM.SITE.DP0.20005.001.01647.HOR.VER.000	sensorVoltage	Main voltage	19	no



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

DGD Agile PN	DPNumber	fieldName	description	Stream Number	Calibration
0320170003	NEON.DOM.SITE.DP0.20005.001.01360.HOR.VER.000	dissolvedOxygenSaturation	Dissolved Oxygen Percent Saturation	5	yes
	NEON.DOM.SITE.DP0.20005.001.01151.HOR.VER.000	dissolvedOxygen	Dissolved Oxygen Concentration	6	no
0320170015	NEON.DOM.SITE.DP0.20005.001.01657.HOR.VER.000	pH	Measurement of pH in water	7	yes
	NEON.DOM.SITE.DP0.20005.001.01658.HOR.VER.000	pHvoltage	pH meter voltage	8	no
0320170005	NEON.DOM.SITE.DP0.20005.001.01667.HOR.VER.000	blueGreenAlgaeRaw	Raw signal of blue-green algae sensor as a percent of full scale detected in the sample	9	no
	NEON.DOM.SITE.DP0.20005.001.01659.HOR.VER.000	blueGreenAlgaePhycocyanin	Blue-green algae phycocyanin concentration in water	10	no
	NEON.DOM.SITE.DP0.20005.001.01666.HOR.VER.000	chlorophyllRaw	Raw signal of chlorophyll a sensor as a percent of full scale detected in the sample	11	no
	NEON.DOM.SITE.DP0.20005.001.01660.HOR.VER.000	chlorophyll	Chlorophyll a concentration in water	12	yes
0320170004	NEON.DOM.SITE.DP0.20005.001.01669.HOR.VER.000	turbidityRaw	Raw signal of turbidity sensor as a percent of full scale detected in the sample	13	no
	NEON.DOM.SITE.DP0.20005.001.01662.HOR.VER.000	turbidity	Turbidity of water as FNU	14	yes



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

DGD Agile PN	DPNumber	fieldName	description	Stream Number	Calibration
0320170006	NEON.DOM.SITE.DP0.20005.001.01668.HOR.VER.000	fDOMRaw	Raw signal of fluorescent dissolved organic matter sensor as a percent of full scale detected in the sample	15	no
	NEON.DOM.SITE.DP0.20005.001.01661.HOR.VER.000	fDOM	Fluorescent dissolved organic matter concentration as quinine sulfate equivalents	16	yes



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

Table 7. Data stream numbers and calibration status with no FDOM

DGD Agile PN	DPNumber	fieldName	description	Stream Number	Calibration
0320170001	NEON.DOM.SITE.DP0.20005.001.01371.HOR.VER.000	conductance	Conductivity at ambient temperture	0	no
	NEON.DOM.SITE.DP0.20005.001.01093.HOR.VER.000	specificConduc tance	Conductivity auto-corrected to 25 degrees C	1	yes
	NEON.DOM.SITE.DP0.20005.001.01378.HOR.VER.000	surfaceWaterT emperature	Temperature in surface water	2	no
HB07530010	NEON.DOM.SITE.DP0.20005.001.01664.HOR.VER.000	sensorDepth	Water depth of measurement	3	no
	NEON.DOM.SITE.DP0.20005.001.01663.HOR.VER.000	sondeSurface WaterPressure	Pressure of surface water measured by the multisonde in psi	4	no
	NEON.DOM.SITE.DP0.20005.001.01670.HOR.VER.000	wiperPosition	Position of wiper	15	no
	NEON.DOM.SITE.DP0.20005.001.01372.HOR.VER.000	batteryVoltage	Battery voltage	16	no
	NEON.DOM.SITE.DP0.20005.001.01647.HOR.VER.000	sensorVoltage	Main voltage	17	no
0320170003	NEON.DOM.SITE.DP0.20005.001.01360.HOR.VER.000	dissolvedOxyg enSaturation	Dissolved Oxygen Percent Saturation	5	yes
	NEON.DOM.SITE.DP0.20005.001.01151.HOR.VER.000	dissolvedOxyg en	Dissolved Oxygen Concentration	6	no



Title: NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		Date: 01/17/2020
NEON Doc. #: NEON.DOC.001166	Author: J. Vance	Revision: F

DGD Agile PN	DPNumber	fieldName	description	Stream Number	Calibration
0320170015	NEON.DOM.SITE.DP0.20005.001.01657.HOR.VER.000	pH	Measurement of pH in water	7	yes
	NEON.DOM.SITE.DP0.20005.001.01658.HOR.VER.000	pHvoltage	pH meter voltage	8	no
0320170005	NEON.DOM.SITE.DP0.20005.001.01667.HOR.VER.000	blueGreenAlgae Raw	Raw signal of blue-green algae sensor as a percent of full scale detected in the sample	9	no
	NEON.DOM.SITE.DP0.20005.001.01659.HOR.VER.000	blueGreenAlgae Phycocyanin	Blue-green algae phycocyanin concentration in water	10	no
	NEON.DOM.SITE.DP0.20005.001.01666.HOR.VER.000	chlorophyllRaw	Raw signal of chlorophyll a sensor as a percent of full scale detected in the sample	11	no
	NEON.DOM.SITE.DP0.20005.001.01660.HOR.VER.000	chlorophyll	Chlorophyll a concentration in water	12	yes
0320170004	NEON.DOM.SITE.DP0.20005.001.01669.HOR.VER.000	turbidityRaw	Raw signal of turbidity sensor as a percent of full scale detected in the sample	13	no
	NEON.DOM.SITE.DP0.20005.001.01662.HOR.VER.000	turbidity	Turbidity of water as FNU	14	yes



<i>Title:</i> NEON Sensor Command, Control and Configuration (C3) Document: Multisonde, Stream		<i>Date:</i> 01/17/2020
<i>NEON Doc. #:</i> NEON.DOC.001166	<i>Author:</i> J. Vance	<i>Revision:</i> F

7.3 Assembly schematic drawing

NA

8 BIBLIOGRAPHY

YSI Inc. (2019) EXO User Manual. YSI Incorporated, Yellow Springs, OH. pp. 181. Manual number 603789, Rev. H.